


Tree Puller Assembly – Detailed Parts Diagram A



Tree Puller Assembly - Parts List A

Item No.	Part Number	Description	QTY.
1	04101-04	Frame Assembly	1
2	04101-02	Arm Assembly	1
3	04101-03	Arm Pin	2
4	04101-01	2x8 Ag Cylinder	1
5	04101-05	Inner Cylinder Box Assembly	1
6	04101-06	Outer Cylinder Box Assembly	1